

Article List English

This offer is open & without engagement.

BLUMAX Digital Camera/Camcorder Batteries



Art.-No.	Description, compatible with	EAN
65002	BLUMAX for Canon BP-208	5060148634142
65003	BLUMAX for Canon BP-310	5060148634159
65097	BLUMAX for Canon BP-511 1400mAh	5060213365650
65009	BLUMAX for Canon BP-511 1700mAh	5060148634166
65001	BLUMAX for Canon BP-522	5060148630335
65269	BLUMAX for Canon BP-809 wireless Li-Ion 2100mAh	5060213371248
65270	BLUMAX for Canon BP-819 Wireless	5060213371255
65271	BLUMAX for Canon BP-827 Wireless 2450mAh	5060213371262
65013	BLUMAX for Canon BP-945	5060148634173
65049	BLUMAX for Canon LP-E4 Li-Ion	5060195317654
65041	BLUMAX for Canon LP-E5	5060148631066
65061	BLUMAX for Canon LP-E6 Black wireless 1800mAh	5060213362475
65088	BLUMAX for Canon LP-E6 white / weiss 1800mah	5060213371743
65254	BLUMAX for Canon LP-E8	5060213362116
65015	BLUMAX for Canon NB-1LH	5060148634180
65016	BLUMAX for Canon NB-2L 800mah	5060148634197
65035	BLUMAX for Canon NB-2L12 / BP-2L12	5060148634203
65036	BLUMAX for Canon NB-2L14/BP-2L14 Li-Ion	5060148634210
65017	BLUMAX for Canon NB-3L Li-Ion	5060148634227
65019	BLUMAX for Canon NB-4LH	5060148634234
65012	BLUMAX for Canon NB-5H Li-Ion	5060148634241
65151	BLUMAX for Canon NB-5L Li-Ion	5060148634258
65038	BLUMAX for Canon NB-6L 890mAh	5060148634814
65047	BLUMAX for Canon NB-7L Li-Ion 890mAh	5060195317630
65261	BLUMAX for Canon NB-8L Li-Ion	5060213362109
65153	BLUMAX for Canon NB-9L Li-Ion Li-Ion 700mAh	5060213371644
65039	BLUMAX for Casio NP-100 Li-Ion	5060148637716
65272	BLUMAX for Casio NP-110 Li-Ion 3,7V	5060213362208
65086	BLUMAX for Casio NP-120 Li-Ion	5055365871159
65020	BLUMAX for Casio NP-20 700mAh	5060148634265
65021	BLUMAX for Casio NP-40	5060148630090
65183	BLUMAX for Casio NP-50 Li-Ion	5060213370333
65042	BLUMAX for Casio NP-60	5060148630304
65052	BLUMAX for Casio NP-90 Li-Ion 1190mAh	5060213370418
65023	BLUMAX for FUJI NP-120 Li-Ion 1900mAh	5060148630106
65044	BLUMAX for FUJI NP-140	5060148637723
65005	BLUMAX for FUJI NP-150	5060148633497
65024	BLUMAX for FUJI NP-40 890mAh	5060148630113
65202	BLUMAX for FUJI NP-50/Pentaxtax D-Li68 Li-Ion 890mah	5060213370357
65025	BLUMAX for FUJI NP-60 Li-Ion 1050mah	5060148631073
65026	BLUMAX for FUJI NP-80	5060148630120
65010	BLUMAX for JVC BN-V416	5060148634500
65011	BLUMAX for JVC BN-V428	5060148634494
65037	BLUMAX for JVC BN-V808	5060148633961
65046	BLUMAX for JVC BN-VF707	5060148630137
65048	BLUMAX for JVC BN-VF714 Li-Ion 2100mAh	5060148630144
65050	BLUMAX for JVC BN-VF733	5060148631080
65006	BLUMAX for JVC BN-VF808	5060148630021

* All Batteries above are replacement Batteries and not Original

Article List English

This offer is open & without engagement.

BLUMAX Digital Camera/Camcorder Batteries



65057	BLUMAX for JVC BN-VF808 wireless Li-Ion	5060213362444
65007	BLUMAX for JVC BN-VF815 press LED before you use !!!	5060148633503
65059	BLUMAX for JVC BN-VF815 wireless Li-Ion	5060213362451
65060	BLUMAX for JVC BN-VF823 wireless Li-Ion	5060213362468
65008	BLUMAX for JVC BN-VF823 with cable 2200mAh	5060148630038
65000	BLUMAX for JVC BN-VM200 Li-Ion	5060148637730
65201	BLUMAX for Kodak KLIC 8000 Li-Ion	5060195317678
65058	BLUMAX for Konica DR-LB1 Li-Ion	5060148630151
65018	BLUMAX for Konica DR-LB4	5060148633510
65029	BLUMAX for Minolta NP-1 Li-Ion	5060148630465
65062	BLUMAX for Minolta NP-200 Li-Ion	5060148630168
65063	BLUMAX for Minolta NP-400 Li-Ion 1500mAh	5060148631097
65022	BLUMAX for Minolta NP-500 / NP-600 Li-Ion	5060148637747
65027	BLUMAX for Minolta NP-700 Li-Ion	5060148633954
65028	BLUMAX for Minolta NP-900 Li-Ion	5060148637754
65067	BLUMAX for Nikon EN-EL1 Li-Ion	5060148630175
65033	BLUMAX for Nikon EN-EL10 / Li-40b	5060148633992
65070	BLUMAX for Nikon EN-EL11 Li-Ion	5060195317661
65072	BLUMAX for Nikon EN-EL12	5060195317685
65093	BLUMAX for Nikon EN-EL14 Li-Ion	5060213372429
65068	BLUMAX for Nikon EN-EL2 Li-Ion	5060148630182
65069	BLUMAX for Nikon EN-EL3 Li-Ion 1550mAh	5060148630199
65152	BLUMAX for Nikon EN-EL3e Li-Ion 1600mAh	5060148631103
65030	BLUMAX for Nikon EN-EL4 Li-Ion 2200mAh	5060148633527
65071	BLUMAX for Nikon EN-EL5 Li-Ion 1100mAh	5060148631110
65031	BLUMAX for Nikon EN-EL8 Li-Ion	5060148633534
65032	BLUMAX for Nikon EN-EL9 Li-Ion 1050mAh	5060148634081
65074	BLUMAX for Olympus BLMI Li-Ion	5060148630205
65075	BLUMAX for Olympus Li-10B Li-Ion	5060148630212
65138	BLUMAX for Olympus Li-40B/EN-EL10/Klic7006/F. Np-45	5060148631189
65043	BLUMAX for Olympus LI-50B 800mAh	5060148637761
65184	BLUMAX for Olympus PS-BLS1 1100mAh	5060213370364
65065	BLUMAX for Panasonic VW-VBG260 wireless Li-Ion 2650mAh	5060213362499
65082	BLUMAX for Panasonic CGA-DU14 Li-Ion 1600mAh	5060148630229
65083	BLUMAX for Panasonic CGA-DU21 Li-Ion	5060148630236
65136	BLUMAX for Panasonic CGA-S005 Li-Ion	5060148630311
65192	BLUMAX for Panasonic CGR-D08S/D120 Li-Ion	5060148631134
65193	BLUMAX for Panasonic CGR-D16S/D220 Li-Ion	5060148631141
65194	BLUMAX for Panasonic CGR-D28S/D320 Li-Ion	5060148631158
65137	BLUMAX for Panasonic CGR-S006 Li-Ion	5060148630328
65034	BLUMAX for Panasonic CGR-S007 Li-Ion	5060148637778
56013	BLUMAX for Panasonic CGR-S008 Li-Ion	5060148633541
75095	BLUMAX for Panasonic DMW-BCA7/S001 Li-Ion	5060148637792
65076	BLUMAX for Panasonic DMW-BCF10E/BCF10	5060213362758
65242	BLUMAX for Panasonic DMW-BCG10E/BCG10	5060213362437
65053	BLUMAX for Panasonic DMW-BCH 7E	5060213362406
65055	BLUMAX for Panasonic DMW-BLB13/BLB13E	5060213362734
65091	BLUMAX for Panasonic DMW-BMB9 Li-Ion 895mAh	5060213365155
65077	BLUMAX for Panasonic VBG070 Wireless	5060213362611

* All Batteries above are replacement Batteries and not Original

Article List English

This offer is open & without engagement.

BLUMAX Digital Camera/Camcorder Batteries



65078	BLUMAX for Panasonic VBG6	5060213362628
65064	BLUMAX for Panasonic VW-VBG130 Wireless 1150mAh	5060213362482
65089	BLUMAX for Pentax D-Li09 1100mah	5060213371767
65087	BLUMAX for Pentax D-Li88 DLI-88/DB-L80 Li-Ion	5060213372085
65243	BLUMAX for Pentax D-Li90 Li-Ion	5060213362987
65081	BLUMAX for Premier DS8330 / DC-8300 / DC8111 Traveler 1250mah	5060213362994
65265	BLUMAX for Samsung BP1310 BP-1310	5060213362710
65090	BLUMAX for Samsung BP-90A Li-Ion	5060213372436
65289	BLUMAX for Samsung IA-BP125A 3,7V Li-Ion	5060213362901
65105	BLUMAX for Samsung SB-L320 Li-Ion	5060148633558
65108	BLUMAX for Samsung SB-LSM320 Li-Ion	5060148630243
65056	BLUMAX for Samsung SLB-10A SLB 10A Li-Ion Compatible	5060213362413
65251	BLUMAX for Samsung SLB-1137D Li-Ion	5060213362727
75043	BLUMAX for Samsung SLB-1237 1230mAh	5060213363007
65264	BLUMAX for Samsung SLB-70A BP-70A Li-Ion 3,7V	5060213362130
65262	BLUMAX for Samsung SLB-11A Li-Ion 900mAh	5060213362123
65111	BLUMAX for Sanyo CR-V3 1500mAh	5060148630250
65268	BLUMAX for Sanyo DB-L90 Li-Ion 3,7V	5060213371231
56011	BLUMAX for Sony NP-BD1 Li-Ion	5060148634104
56010	BLUMAX for Sony NP-BG1 1000mah	5060148634067
65260	BLUMAX for Sony NP-BN1	5060213362178
56009	BLUMAX for Sony NP-F550 Lion	5060148637808
56007	BLUMAX for Sony NP-FA50 Li-Ion	5060148630519
56008	BLUMAX for Sony NP-FA70 Lion	5060148637815
65126	BLUMAX for Sony NP-FC10 Li-Ion	5060148630267
65191	BLUMAX for Sony NP-FH100 wireless Li-Ion	5060148630380
65197	BLUMAX for Sony NP-FH50 wireless Li-Ion	5060195317722
65196	BLUMAX for Sony NP-FH70 wireless Li-Ion	5060195317623
65130	BLUMAX for Sony NP-FM50 1800mAh	5060148630342
56015	BLUMAX for Sony NP-FM500H Li-Ion 1650mah	5060195317647
65131	BLUMAX for Sony NP-FM70 Li-Ion	5060148631165
65132	BLUMAX for Sony NP-FM90 Li-Ion	5060148631172
65133	BLUMAX for Sony NP-FP50 Li-Ion	5060148630274
65134	BLUMAX for Sony NP-FP70, HC 23e Li-Ion	5060148630281
65135	BLUMAX for Sony NP-FP90 HCI7 1650mah Li-Ion	5060148630298
60039	BLUMAX for Sony NP-FR1	5060148637839
56006	BLUMAX for Sony NP-FS11 Lion	5060148634074
56005	BLUMAX for Sony NP-FT1	5060148637822
65080	BLUMAX for Sony NP-FV100 wireless Li-Ion 7,4V	5060213371293
65084	BLUMAX for Sony NP-FV50 wireless Li-Ion	5060213362888
65079	BLUMAX for Sony NP-FV70 wireless Li-Ion 7,4V	5060213371279
65066	BLUMAX for Sony NP-FV70 with cable Li-Ion 7,4V	5060213362505
65290	BLUMAX for Sony NP-FW50 7,4V Li-Ion 900mAh	5060213363014
75044	BLUMAX for Sony VBD-070 wireless Li-Ion	5060213361911

* All Batteries above are replacement Batteries and not Original