

Article List English

This offer is open & without engagement.

Camcorder/Digital Camera Battery Multicharger & Interchangeable Battery Pack Adapters



| Art.-Nr | Bezeichnung | Plate typ | EAN |
|---------|---|-----------|---------------|
| 90204 | Universal Ladegerät, Digitalkam. 1000mA | Box | 5060195313618 |
| 90194 | BLB BAT-03087-003 Charger Plate | LP729 | 5060195314172 |
| 90183 | BLB BAT-06860-001 Charger Plate | LP710 | 5060195314141 |
| 90197 | CAN BP-208/214/308/315 C.-Plate | LP508 | 5060195314059 |
| 90105 | CAN BP-511/512/522/535 C.-Plate | LP511 | 5060148630632 |
| 90125 | CAN BP-617/608 Charger Plate | LP608 | 5060195314073 |
| 90167 | CAN BP-711 Charger Plate | LP711 | 5060195314158 |
| 90230 | CAN BP-808/809/819/827 Charger Plate | LP808 | 5060195314219 |
| 90127 | CAN BP-911/914/915/930 C.-Plate | LP914/915 | 5060195314288 |
| 90226 | CAN LP-E5 / BP85ST C.-Plate | LPE5 | 5060195314325 |
| 90234 | LPE6 CAN LP-E6 C.-Plate | LP | 5060213365636 |
| 90032 | CAN LP-E8 Charger Plate | LP | 5060213364165 |
| 90120 | CAN NB-1L/NB-3L KON DR-LB4 MIN NP-500/NP-600 C.-Plate | LP1 | 5060148630649 |
| 90102 | CAN NB-2L/BP-2L12/2L14/2L18 C.-Plate | LP234 | 5060148630410 |
| 90103 | CAN NB-3L Charger Plate | LP334 | 5060148630656 |
| 90122 | CAN NB-4L NB-8L SAM BP125-A C.-Plate | LP46 | 5060148630663 |
| 90107 | CAN NB-5H Charger Plate | LP5 | 5060148630670 |
| 90175 | CAN NB-5L C.-Plate | LP56 | 5060148630687 |
| 90225 | CAN NB-6L/SAM SLB-10A C.-Plate | LP6L | 5060195314127 |
| 90141 | CAN NB-7L C.-Plate | LP | 5060213361027 |
| 90108 | CAS NP-20 C.-Plate | LP20 | 5060148630694 |
| 90109 | CAS NP-40 C.-Plate | LP240 | 5060148630700 |
| 90228 | CAS NP-60 C.-Plate | LPC60 | 5060195314318 |
| 90146 | CAS NP-90 C.-Plate | LP | 5060213370760 |
| 90240 | CAS NP-120 Charger Plate | LP | 5060213365674 |
| 90189 | DELL T6476/T6845 Charger Plate | LP647 | 5060195314103 |
| 90027 | E,EU-94 C.-Plate | LP940 | 5060195313670 |
| 90217 | EPS EU-97 Charger Plate | LP970 | 5060195314295 |
| 90229 | FUJ NP-140/OLY BLS-1/SAM BP80W C.-Plate | LPF140 | 5060195314349 |
| 90111 | FUJ NP-40 PEN D-L18 Klic-7005 DMW-S004 SAM 0837 C.-Plat | LP40 | 5060148630724 |
| 90224 | FUJ NP-50 Charger Plate | LPF50 | 5060195314356 |
| 90119 | FUJ NP-80/100 RIC DB-20 KOD Klic-3000 C.-Plate | LP80 | 5060148630731 |
| 90215 | FUJ NP-95 Charger Plate | LP95 | 5060148630625 |
| 90023 | IRiv BP 009 LP9 Charger Plate | LP009 | 5060195313748 |
| 90223 | JVA BN-VF808/815/823 C.-Plate | LP | 5060195313731 |
| 90101 | JVC BN-V107/114/115/118 C.-Plate | LP107 | 5060195313762 |
| 90114 | JVC BN-V306 Charger Plate | LP306 | 5060195313946 |
| 90198 | JVC BN-V37U Charger Plate | LP37 | 5060195313960 |
| 90115 | JVC BN-V408/BN-V416/BN-V428 C.-Plate | LP408 | 5060195313984 |
| 90176 | JVC BN-V507/514 Charger Plate | LP507 | 5060195314042 |
| 90199 | JVC BN-V712 / 714 Charger Plate | LP712 | 5060195314165 |
| 90219 | JVC BN-V907U Charger Plate | LP907 | 5060195314271 |
| 90117 | JVC BN-VF707/714/733 C.-Plate | LP707 | 5060148630526 |

Article List English

This offer is open & without engagement.



& Adapters

| | | | |
|-------|---|--------|---------------|
| 90165 | JVC BN-VG114/107/1121 C.-Plate | LP | 5060213364158 |
| 90137 | JVC BN-VM200 C.-Plate | LP208 | 5060195313878 |
| 90017 | KOD Klic 7003 Charger Plate | LP773 | 5060195314196 |
| 90118 | KOD KLIC-5001/FUJ NP-60/95/NP-120/RIC DB-40 | LP61 | 5060148630748 |
| 90216 | KOD KLIC-7001 Charger Plate | LP771 | 5060148630533 |
| 90172 | KOD KLIC-7002 Charger Plate | LP772 | 5060148630540 |
| 90116 | KON DR-LB1 Charger Plate | LP51 | 5060148630755 |
| 90106 | KON DR-LB4 Charger Plate | LP4 | 5060148630762 |
| 90182 | KYO BP-1100S Charger Plate | LP411 | 5060148630779 |
| 90210 | KYO BP-760S Charger Plate | LP760 | 5060195314189 |
| 90121 | KYO BP-780S Charger Plate | LP22 | 5060148630816 |
| 90123 | MIN NP-200 Charger Plate | LP202 | 5060148630786 |
| 90124 | MIN NP-400 Charger Plate | LP400 | 5060148630793 |
| 90126 | MIN NP-700/SAN DB-L30 C.-Plate | LP700 | 5060148630809 |
| 90143 | MIN NP-900 C.-Plate | LP249 | 5060148630557 |
| 90024 | MOL MCR 182IH LP1821 Charger Plate | LP1821 | 5060195313830 |
| 90128 | NIK EN-EL1/MIN NP-800 C.-Plate | LP112 | 5060148630823 |
| 90227 | NIK EN-EL1/D-Li78/Li-50b/BK1 C.-Plate | LPEL11 | 5060195314332 |
| 90231 | NIK EN-EL12 Charger-Plate | LPEL12 | 5060213363830 |
| 90129 | NIK EN-EL2 C.-Plate | LP125 | 5060148630830 |
| 90130 | NIK EN-EL3/EN-EL3e/FUJ NP-150 C.-Plate | LP135 | 5060148630847 |
| 90131 | NIK EN-EL5 C.-Plate | LP155 | 5060148630854 |
| 90132 | NIK EN-EL7 C.-Plate | LP177 | 5060148630861 |
| 90134 | NIK EN-EL8/Klick7000 C.-Plate | LP189 | 5060148630878 |
| 90020 | NIK EN-EL9 C.-Plate | LP196 | 5060195313854 |
| 90235 | OE BK1/Li-50b C.-Plate | PL | 5060213365421 |
| 90233 | OE NIK EN-EL11 C.-Plate | LPEL11 | 5060213364141 |
| 90135 | OLY BLMI C.-Plate | LP101 | 5060148630885 |
| 90144 | OLY CR-V3 Charger Plate | LP3 | 5060195313922 |
| 90133 | OLY LI-10B/SAN DB-L10 C.-Plate | LP110 | 5060148630892 |
| 90145 | OLY LI-30B C.-Plate | LP130 | 5060148630908 |
| 90171 | OLY LI-40B/EN-EL10/CNP-80 C.-Plate | LP140 | 5060148630915 |
| 90045 | OLY Li-50B/SON BK1 Charger Plate | LP | 5060213365414 |
| 90190 | OLY PS-BLL1 Charger Plate | LP102 | 5060148630922 |
| 90019 | OLY PS-BLS1/BP80W/NP-140 C.-Plate | LP106 | 5060195313755 |
| 90187 | PalmOne 157-10014-00 Charger Plate | LP650 | 5060195314110 |
| 90033 | PAN BCH7 Charger Plate | LP | 5060213363847 |
| 90018 | PAN CGA S008 E/S005 E/DMW-BCE10E C.-Plate | LP168 | 5060195313809 |
| 90158 | PAN CGA-DU07/14/21 HIT DZ-BP07S/14S/14SW C.-Plate | LP407 | 5060148630939 |
| 90148 | PAN CGA-S003 Charger Plate | LP21 | 5060148630946 |
| 90170 | PAN CGA-S007E/FUJ NP-30 C.-Plate | LP171 | 5060148630564 |
| 90181 | PAN CGA-S303 Charger Plate | LP303 | 5060195313939 |
| 90159 | PAN CGR-D120/D220/D320/DMW-BL14 C.-Plate | LP120 | 5060195313786 |
| 90156 | PAN CGR-V610 Charger Plate | LP610 | 5060195314097 |
| 90218 | PAN DMW-BC7 Charger Plate | LP7 | 5060195314134 |
| 90104 | PAN DMW-BCA7/S001 C.-Plate | LP17 | 5060195313816 |
| 90188 | PAN DMW-BCB7/S004 Charger Plate | LP187 | 5060195313847 |
| 90029 | PAN DMW-BCG10E/BCF10E Charger Plate | LP | 5060213361041 |
| 90030 | PAN DMW-BLB13E Charger Plate | LP | 5060213361058 |
| 90236 | PAN DMW-BMB9 Charger Plate | LP | 5060213365667 |
| 90140 | PAN S006/S002E/DMW-BM7 C.-Plate | LP77 | 5060148630618 |
| 90239 | PAN VW-VBK-180 /VBK 360 / VBK180 / Charger Plate | PL | 5060213365193 |

Article List English

This offer is open & without engagement.



| | | | |
|-------|---|-------|---------------|
| 90008 | PEN D-Li90 Charger Plate | LP | 5060213363861 |
| 90110 | PRE 8300 DP Charger Plate | LP | 5060195314431 |
| 90025 | QTE ST26A/40700102 Charger Plate | LP263 | 5060195313915 |
| 90211 | RIC DB-50/Klic 8000 Charger Plate | LP850 | 5060195314240 |
| 90195 | ROL 02491-0028-00/DS 8330 Charger Plate | LP830 | 5060195314233 |
| 90042 | SAM BP-1310 Charger Plate | LP | 5060213363878 |
| 90041 | SAM BP-70A/PL-80/ ES-65/ES-70 Charger Plate | LP | 5060213363885 |
| 90142 | SAM SB-L110/160/220/320/480 C.-Plate | LP16 | 5060148630960 |
| 90161 | SAM SBL-1437 Aufsatz f. Ladegerät | LP | 5060213361065 |
| 90213 | SAM SB-L70G Charger Plate | LP870 | 5060195314257 |
| 90160 | SAM SB-LSM80/LSM160/LSM320 C.-Plate | LP800 | 5060148630977 |
| 90220 | SAM SB-P90A/PI80A C.-Plate | LP900 | 5060195314264 |
| 90021 | SAM SLB 0837(B)/KYO BP-760s C.-Plate | LP413 | 5060195314004 |
| 90022 | SAM SLB 1137C C.-Plate | LP793 | 5060195314202 |
| 90031 | SAM SLB 1137D C.-Plate | LP | 5060213364134 |
| 90000 | SAM SLB-0937 C.-Plate | LP | 5060195314301 |
| 90004 | SAM SLB-1237 Charger Plate | LP | 5060213363892 |
| 90196 | SAM SLB-1974 C.-Plate | LP815 | 5060195314226 |
| 90044 | SAM SLB-70A BP-70A Charger Plate | LP | 5060213363908 |
| 90147 | SAN DB-L20 C.-Plate | LP132 | 5060148630984 |
| 90177 | SAN DB-L40 Charger Plate | LP410 | 5060195313991 |
| 90221 | SAN URI21/124 Charger Plate | LP122 | 5060195313793 |
| 90192 | SHP BT-L1/2/2U Charger Plate | LPL2 | 5060195314363 |
| 90214 | SHP BT-L221/241 Charger Plate | LP221 | 5060195313892 |
| 90162 | SHP BT-L225/L445 Charger Plate | LP225 | 5060195313908 |
| 90163 | SHP BT-L226U Charger Plate | LP226 | 5060148630991 |
| 90180 | SHP BT-L31 Charger Plate | LP31 | 5060195313953 |
| 90178 | SHP BT-L44 Charger Plate | LP44 | 5060195314028 |
| 90174 | SON NP-BG1 C.-Plate | LP181 | 5060195313823 |
| 90184 | SON NP-F100/200 Charger Plate | LP200 | 5060148631004 |
| 90173 | SON NP-FA50/FA70 C.-Plate | LP555 | 5060148630571 |
| 90149 | SON NP-FC10 C.-Plate | LP10 | 5060148631011 |
| 90153 | SON NP-FE1 C.-Plate | LP577 | 5060148631028 |
| 90150 | SON NP-FF50/FF70 C.-Plate | LP50 | 5060195314035 |
| 90151 | SON NP-FM50F/FM500H/F550/F960/VW-VBDI/BN-V607 C.-Plate | LP550 | 5060148631035 |
| 90152 | SON NP-FP50/70/90/NP-FH50/70/100/NP-FV50/70/10 C.-Plate | LP55 | 5060148630588 |
| 90154 | SON NP-FS10/FS11/FS21 C.-Plate | LP111 | 5060148631042 |
| 90155 | SON NP-FI1/NP-BDI/NP-FRI C.-Plate | LP113 | 5060148631059 |
| 90237 | SON NP-FW50 Charger Plate | PL | 5060213365186 |
| 90185 | SON PSP-110 Charger Plate | LP210 | 5060195313885 |
| 90191 | SYM SM-470i Charger Plate | LP560 | 5060195314066 |